




Bulldog dart - A4 fold lines. Print at 100% (Actual size), printed side up.
Blue dashes: valley fold (towards you). Red dash-dot: mountain fold (away from you).
Numbers are the steps on page 2. Grey dots near the back edge: bend up here for elevators.

How to fold the Bulldog dart


Difficulty: medium - best for: Distance. Start with page 1 printed side up.




1 Lay the sheet portrait, printed side up. Fold it in half lengthwise, crease firmly and unfold again. The centre crease is your guide for every fold that follows.




2 Fold both top corners in to the centre crease.




3 Fold the point down so the tip touches the centre crease where the two flaps end. The top is now flat.




4 Fold the slanted sides in to the centre crease once more, as for a dart. The nose stays blunt.



5 Turn the plane over and fold it in half along the centre crease, so the folded flaps end up on the outside. Turn it so the nose points left.



6 Fold the top wing down so its top edge lies along the bottom edge (the keel). Turn over and fold the other wing to match.



7 Open the wings until they are flat and level, with a slight upward V from the front.

Throwing and trimming

- Throw it hard and straight, like a dart. The blunt nose makes it a little slower but sturdier.
- Aim slightly upward for distance outdoors.
- Dives: bend the back edges of the wings up a little.
- Rolls to one side: make sure the two wings are equal; a small up-bend on the low wing's back edge helps lift it.